



For bipolar (+ and -) outputs install
C1, C3, C4, C6, R1, and R2

For single-ended output
install C5, C2, and R2
Short R1

www.pmlillett.com
Copyright 2010 Pete Milllett

Bias Supply PCB

TITLE: BIASSUP

Document Number:

REV:

Date: 11/22/2010 11:15:20a

Sheet: 1/1